

Mystic CLEANERS

Just Add Water to Remove Tough Stains, Dirt & Grime

Dual Purpose Mystic Eraser

Mystic Eraser Dual Purpose scrubby eraser sponges are ideal for cleaning those deeper, built-in grime surfaces. They are constructed of a non-scratch, extra abrasive scouring pad that won't break down. The pad is then bonded to an open cell structured melamine eraser sponge that is 100% identical to the material used in the Mr. Clean Magic Eraser®.

The variety of cleaning applications for this product has easily made it one of the most popular and effective cleaning products worldwide.

Compared to 3M Scotch-Brite™ pads, our scrubby sponges are a versatile alternative that can clean stubborn stains including dirt, grease, grass, rust, and dyes can be cleaned with little to no effort because of the open cell structure eraser and durable scratch pad.

Using only water to activate it's deep scrubbing ability, eraser sponges can effectively clean most stains with a simple back and forth movement. No soaps or chemical cleaners are required making our sponges safe for you, your workplace and the environment.



Commerical Applications

- Restrooms
- Grout & tiles
- Graffiti
- Floors
- Windows
- Walls
- Vinyl surfaces
- Baseboards
- Countertops
- White boards
- Appliances
- Mirrors
- Building exteriors
- Outdoor furniture
- Pools & Spas
- Pots, pans & dishes
- Auto interiors
- Tires & Rims
- Boats & Planes and more

Directions for Use

Wet, Squeeze Excess Water, Rub Clean

Do Not Use on skin or other parts of the body. Before use on a new area, test on a small inconspicuous area with light pressure to ensure it does not scratch the surface. Eraser sponges are not recommended for use on surfaces that are polished or glossy or have a brushed, satin or faux finish.

www.mysticclean.com